

TOOL PACKING LIKE A PRO



ESSENTIAL THINGS YOU NEED TO
KNOW ABOUT CAMERA BAGS

ACCESSORIZEYOURCAM.COM

© Copyright 2019–All rights reserved.

This document is geared toward providing exact and reliable information in regard to the topic and issue covered. The publication is sold with the idea that the publisher is not required to render accounting, officially permitted, or otherwise, qualified services. If advice is necessary, legal or professional, a practiced individual in the profession should be ordered.

-From a Declaration of Principles which was accepted and approved equally by a Committee of the American Bar Association and a Committee of Publishers and Associations.

In no way is it legal to reproduce, duplicate, or transmit any part of this document in either electronic means or in printed format. Recording of this publication is strictly prohibited and any storage of this document is not allowed unless with written permission from the publisher. All rights reserved.

The information provided herein is stated to be truthful and consistent, in that any liability, in terms of inattention or otherwise, by any usage or abuse of any policies, processes, or directions contained within is the solitary and utter responsibility of the recipient reader. Under no circumstances will any legal responsibility or blame be held against the publisher for any reparation, damages, or monetary loss due to the information herein, either directly or indirectly.

Respective authors own all copyrights not held by the publisher.

The information herein is offered for informational purposes solely, and is universal as so. The presentation of the information is without contract or any type of guarantee assurance.

The trademarks that are used are without any consent, and the publication of the trademark is without permission or backing by the trademark owner. All trademarks and brands within this book are for clarifying purposes only and are owned by the owners themselves, not affiliated with this document.

Table of Contents

Introduction

Chapter 1: The Basics of Camera Bags

What Are Camera Bags?

What Are the Major Components of Camera Bags?

Benefits of Using Camera Bags

Chapter 2: A Closer Look Into Camera Bags

Different Types of Camera Bags

Which One Suits You Best?

Chapter 3: Tidying-Up Your Camera Bag

How to Organize Camera Bags

Proper Care and Maintenance

Chapter 4: Other Camera Bag Essentials

Helpful Tips and Tricks to Consider

Camera Bags Must-Have Accessories

Conclusion

Introduction

So you got yourself a new camera unit, and as a bonus, you also got a few lenses and accessories to match it perfectly. *Big investment, isn't it?*



By this time, you are probably worried about damaging, breaking, or even scratching any of them. The best thing that you can do is to invest in a great camera bag! This solid and versatile investment will safely hold, carry, and store your gear and stuff in style.

Looking at the various camera bags available, you will understand that the preference of every user varies depending on their needs. With that, let's take a look at some helpful information on camera bags to ensure tool packing like a pro!

Chapter 1: The Basics of Camera Bags

It is undeniably true that camera bags are as valuable as your cameras and gears. As simple as it may seem, but these bags are the best companion for every photo shoot and sessions. In this chapter, we'll try to discover some basic information about camera bags.

What Are Camera Bags?

Camera bags are essential not only for professionals but also for amateur and casual photographers. Without them, you may find it difficult to carry your stuff during photoshoots, travels, or leisure.

These bags are usually made with soft padding to ensure the protection of cameras, lenses, and other parts against damage. Their soft lining also keeps your valuable investments safe from being scratched, especially when dropped or hit on surfaces.

Most camera bags are designed with different compartments to hold stuff such as gadgets and their accessories. They are also equipped with one to two straps for easy carrying with the hand or across the chest.

What Are the Major Components of Camera Bags?

Camera bags come with a variety of options to choose from. Each of them has their own unique set of features and components that make them stand out among the rest.

1. Material and Construction

No matter where you bring or tag along with your camera bags, it is important that they can withstand wear and tear. They should also be breathable enough to ensure the safety of your gadgets, even during heart raising activities.

The materials of the bag play a significant role in keeping your essentials safe and protected against several unwanted factors. Here are some of the materials commonly used in making camera bags.

- **Natural Fibers**

Leather gives your bag a refined and timeless appeal that can last for years. It is sturdy enough to handle heavy weights and prevent dirt from catching up easily. Leather, however, is a bit heavier due to the volume of the material itself.

Cotton bags have a smoother and finer texture, yet resilient enough to wear and tear. This material offers a variety of styles and designs. Cotton material, though, tends to get dirty more quickly due to its lighter colors.

Canvas is highly breathable and keeps your bag dry even in humid environments. It also helps prevent static electricity, which can affect your digital and electronic equipment.

- **Man-Made Hi-Tech Materials**

An example of this is ballistic nylon. This thick and durable material features waterproof coating, puncture resistance, and abrasion resistance to ensure the safety of your items.

- **Polyester Material**

This synthetic fiber is strong and flexible enough to prevent wrinkling and shrinking. It also dries quickly, making it an excellent fabric for different weather conditions.

Additionally, these materials used can also affect the weight of your bag. The way they are bound together, whether through stitching or gluing, also affects their durability.

2. Opening and Closing Mechanisms

The opening and closing mechanism of camera bags may depend greatly on how fast you will need your camera out of the bag. The most common materials used include zipper, Velcro, and magnets.

Zippers help prevent your camera from getting wet, but they also have the potential of scratching your devices due to negligence. Low-quality zippers can potentially and unexpectedly fail, causing them to break and fall out.

Velcro offers excellent strength and low maintenance, requiring only an easy press on the fabric to ensure being locked together. Despite its great bonding strength, this material can easily catch dirt, lint, and other particles that can compromise its performance.



Magnet-based mechanisms allow ease of access to the inside of your bag. This material, though, does not offer the protection needed by your gear against different weather conditions.

3. Pockets and Compartments

Camera bags come with various designs depending on style. Nonetheless, no matter what type you choose, they always come with multiple pockets and compartments on various parts of the bag.

These partitions, which usually come in different sizes, make it easy for you to take out the items needed. They can also act as storage areas to perfectly hold and snug items to prevent accidental falls and jumbles on your bag.

Notice that the compartments are ergonomically positioned on easily accessible angles and locations to ensure quick access to all your stuff, such as cameras and lenses.

Benefits of Using Camera Bags

Camera bags are beneficial not only for the devices that they can hold but also to the ones using them. Given the following benefits of camera bags, *why wouldn't you consider investing in one?*

1. *Protects Your Stuff*

Camera bags help protect your investment, whether it is your camera, lenses, or accessories. These electronic items can cost a huge amount of your money, so it is best to have them appropriately stored for safekeeping.

Moreover, these bags are waterproof on the outside, adding protection even when working on rainy days. With its high-quality materials, the camera bags are guaranteed to dry quickly while repelling moisture on the inside.

2. *Promotes Ease and Comfort*

Being padded with a soft lining, camera bags give more comfort when being carried either by the hand or shoulder. Its padding runs from the straps to the inside of the bag, giving you peace of mind even when you accidentally hit against things.

3. *Comes in Different Styles*

Camera bags are available in various styles, sizes, and colors, depending on your personality and style. They will surely bring the joy that you may want to use and carry them daily. Other than the design, they also come in a wide range of prices to fit in your budget.

Chapter 2:

A Closer Look Into Camera Bags

Just like any other stuff and accessories, camera bags are available in various styles and designs, which allow you to choose the best that will fit your needs. In this chapter, we will let you navigate the world of camera bags for better knowledge and comparison.



Different Types of Camera Bags

Being fab and in-style during photoshoots is easy with the availability of camera bags featuring unique styles and specifications. Here are the most common types of camera bags in the market.

- **Shoulder Bag:** This is a smaller-sized bag with a shorter strap that can go over your shoulder and falls on your rib cage. It is very light and allows easy access due to the limited space.
- **Messenger Bag:** This type is similar to shoulder bag except that it is slightly larger and comes with a longer strap. When worn, it can be strung across the body and usually falls to the hip.

- **Holster Bag:** The holster bag is attached to some sort of garments such as a durable belt or a chest harness. It is smaller than a shoulder bag, so it can only hold fewer items at a time.
- **Backpack:** Backpacks tend to have more space to carry cameras, lenses, and other accessories. They offer comfort and flexibility due to their design, which includes compartments for various gears such as your laptop. There is an issue on access when backpacks are used, though, since you have to take it off first to get your stuff.
- **Roller Bag:** A roller bag has a similar capacity to that of a standard backpack, but this type is meant to be rolled out on the ground. Do note that this bag is not meant for rugged and remote works due to difficulty in the navigation of your stuff.
- **Backpack Insert:** This large accessory is meant to fit into larger backpacks. This is a common choice among photographers due to the comfort and additional features that it offers.

Which One Suits You Best?

Every photographer, both amateur and professional, are aware that camera bags are as essential as their actual gears. While you spend a lot of bucks on your camera and its lenses, you should also take camera bags as precious investments. Knowing what type of camera bag suits you best is significant to ensure its optimum functioning against accidents, poor weather, and thieves.

Ask yourself. *Are you an amateur photographer who only aims for comfort?* Then a shoulder bag or a messenger type fits you best. *Are you a traveling photographer who needs maximum gear protection?* Try to consider a full-fledged backpack or roller bag to keep in your gears.

No matter what your preference is, there is a camera bag that you can use. You just have to pay attention to the bag's details to bring out its optimum functioning system.

Chapter 3: Tidying-Up Your Camera Bag

A well-designed camera bag will give you more control of your stuff. Learning how to organize and maintain it in good working condition will save you precious time, money, and energy for a more enjoyable and comfortable experience.

How to Organize Camera Bags

A camera bag houses and protects your gears and its accessories. Being a portable one, it allows you to have all the necessary photography stuff right at your fingertips. However, to use it effectively, the camera bag must be organized. This will also save you time by giving quick access to all the stuff in your bag.

Once you have chosen a camera bag with multiple compartments, it's time to organize your camera and its accessories by following these simple steps.

Step #1: Place the Camera

The compartment dedicated to your camera may include slots for the different types and sizes of cameras. Be sure to choose the slot where your camera fits best.

Insert the camera with the lens facing the bottom of the bag to allow easy pulling out when needed. With that said, you must ensure that the lens cap is on the camera to avoid any damages and scratches to the lens.

Step #2: Organize the Lenses, Flashes, and Filters

Your camera bag also comes with compartments made explicitly for your lenses. These slots should perfectly match the size of your lenses to ensure better protection.

As an added recommendation, place filters on empty slots nearby since they are in conjunction with the use of the lenses. Find any available slots in the bag to house your flash accessories, as well.

Step #3: House the Battery

The camera batteries should be kept in one of the compartments to allow quick access. Used batteries should be stored separately to avoid confusion.

Step #4: Store Memory Cards

Memory cards are the smallest item for photography needs. They should be stored carefully in inner pockets with zippers. If your camera bag doesn't come with this feature, a small resealable bag can be used. Place the resealable pouch with memory cards on one of the compartments to prevent any damage and loss.

Step #5: Keep Other Maintenance Supplies

Be sure to have space or room for your cleaning cloths. This essential stuff should be kept handy for any quick cleaning requirements. A small can of compressed air can also be useful in cleaning dirt and dust from the equipment.

Step #6: Bring Your Manual

For newbies and beginners, having your camera's manual on your bag is useful. This can be placed on the outer pocket or slid along the inside pockets of your bag.

Step #7: Additional Padding

The camera bag has padding, but adding some more will further enhance the protection of your gear and equipment. Place the padding in any open spaces that will not block access to your accessories.

With all the steps and items needed, always make sure you avoid overfilling your camera bag, as this will be difficult to close.

Proper Care and Maintenance

Camera bags are designed to protect your gear, so it is fair enough that you also give utmost care to them to ensure their optimum performance and stylish appearance at all times. Here are some tips on how to properly care and maintain your camera bags.

- Remove any padded inserts, base foam, and dividers before washing.
- Avoid putting the bag into a washing machine. Dry cleaning service is a big “No!” since too much pressure may be harsh for the bag, especially on its special water-resistant coating.
- Do not use detergent soaps since they can ruin your bag, especially if made with leather.
- Place the bag on a draining board and wash using warm soapy water and a nail brush to remove stubborn dirt.
- Be sure not to scrub hard as it might lighten the color of your bag.
- Never submerge the bag into the water.
- Wash the soap away using clear water.
- Allow the bag to dry naturally with less exposure to heat and acids. Excessive exposure might affect the waterproofing feature of your bag.
- Don’t put the bag in a tumble dryer or any equivalent device.
- After drying, apply recommended dressings to binding areas.
- Always store your bag in a clean and dry place to prevent mold growth and bad smell.
- Vacuum the bag regularly to remove dirt and sand that can damage your gears and its accessories.

Chapter 4: Other Camera Bag Essentials

To maximize the full potential of your camera bags, customization is the primary key. With the simple tips and accessories available, you are guaranteed to enjoy every single part of your valued photography investment.



Helpful Tips and Tricks to Consider

Camera bags tend to be a trivial thing, especially for beginners. With few photography sessions and gigs, though, you'll soon realize that your bag is not only for gear security but also for comfort and ease of use. Below are some of the helpful tips in making the most out of your camera bag.

1. Pack Like a Boss

Keep in mind that the smarter you pack, the more likely your gear will be more organized and easier to find. *The secret?* Practice!

Don't cram and pack stuff into your bag the night before your photography trips and outings. Instead, try to experiment for different arrangements. If needed, change the architectural structure of the compartments by simply moving the dividers depending on your specific needs.

Lastly, be sure that all your gear and equipment are packed snugly. This will not only ensure protection but will also help maximize the space in your bag.

2. Take What You Need

You don't need to bring along every single piece of gear of your camera in every photoshoot. There is a higher chance that you will only use a few from those multiple packs.

So what's the point here? Prepare for different events that may occur, but you don't have to cram and stuff everything in your bag.

Try to increase the likelihood that something can be broken or get lost. On top of that, plan and figure out what you need to take with you, and then pack them accordingly.

3. Invest in a Good Bag

Packing and organizing your gear and stuff is a lot easier if you invest in a good quality camera bag. With the various types of bags available, some are just simply better than others.

For beginners, be sure to check its construction and give attention to details. The bag may look stunning, yet will not be able to fulfill your needs.

Camera Bags Must-Have Accessories

Congrats, you got yourself a camera bag! However, you still feel completely disorganized, uncomfortable, and unprotected when you use it. Check out these must-have accessories to help you customize your bag.

For Organization

- A dedicated case for your memory cards helps keep everything neat and organized. It can even go a long way as it also serves as a protective barrier against dirt and dust.
- Batteries, especially the small ones, are hard to track when placed inside the camera bag. The use of battery holders will help keep your camera batteries together. As a bonus, there are some holders which allow groupings and organization based in types and power levels.



- Camera filters are also prone to damage and loss in the shuffle. Using a filter pouch will not only protect them but will also help for easier identification.

For Protection

- Protecting your lenses is as important as protecting your camera. The different sizes of fold-over pouches give snug-fitting cushions for the glasses. Also, they allow quick access to your lens due to its unique design.
- Protective wraps are considered to be the jack-of-all-trades in the field of photography storage. They are perfect for giving additional padding, especially to awkwardly shaped gears.
- A rain cover can quickly ease up your paranoia about the rain damaging your camera and lenses. This accessory will add an extra layer of protection to your gear, allowing you to shoot even in less allowable weather conditions.

- Locks are necessary if you are traveling or planning to check in your camera bag. A combi-lock is the best option for ease and comfort.

For Cleaning

- Lens wipes are essential at all times, and there is no exception to that. It is best to make them always available in your bag. If possible, choose wipes that are individually packed, non-abrasive, and pre-moistened.
- If you are using mirrorless cameras, have a sensor cleaning kit handy. This is a special tool to help minimize camera bag footprints while ensuring protection against dust and dirt.

For Preparation

- Have a conventional multi-tool ready in your camera bag as this is the simplest yet frequently used tool for all your camera adjustments.

Conclusion

Camera bags are as important as your camera and lenses. They are valuable investments that help protect your stuff while you're enjoying every single moment of your shoot or trip. These bags come in various styles and designs to fit your preferences.

Some may find the use of camera bags a bit challenging due to the various parts and compartments present. But, as you go along its organizational features, you'll find its use very efficient and enjoyable.

Moreover, with the helpful tips and must-have accessories, you are guaranteed to have the most out of this amazing product. If that weren't enough and you want to know more about camera bags, check out our [website](#).